

# AGORA SOCCER WATCH INSTRUCTION MANUAL

MODEL: SA-7700

## FEATURES:

1. Hour, Minute, Second, Date, and Weekday
2. Soccer timer and stoppage timer to keep track of stoppage time
3. 12/24 Hour Format, auto calendar
4. Alarm
5. Chronograph, 1/100 second, measure up to 9 hours 59 minutes and 59.99 seconds
6. 10 recallable lap and split memories



## Time Mode


### A) Time Display:

- Press D to cycle between the 4 display modes:  
(Time → Alarm → Chronograph → Soccer Timer)
- Press A when showing Time to display Year
- Press B when showing Time to switch between 12/24 Hour format  
(In the 12 Hour Mode it shows A or P for am/pm)



### B) Time Setting:

- Press C when showing Time and hold for 2 seconds to enter into Time Setting Mode, the seconds digits start flashing
- Press A to reset Seconds to 00
- Press B to sequentially select and adjust  
(Seconds → Minutes → Hour → Year → Month → Day)
- Use A to adjust the Minutes, Hour, Year, Month, and Day
- Press C when finished adjust the Time Settings



## Alarm Mode

### Alarm Display:

- Press D to cycle between the 4 display modes:  
(Time → Alarm → Chronograph → Soccer Timer)
- Press A when showing Alarm to turn it On/Off
- Press C when in Alarm and hold for 2 seconds to enter into Alarm Setting Mode, the Hour digit(s) start flashing
- Press B to sequentially select and adjust  
(Hour → Minutes)
- Use A to adjust the Hour, and Minutes
- Press C: To complete Alarm Setting



## Chronograph Mode

### Chronograph Display:

- Press D to cycle between the 4 display modes:  
(Time → Alarm → Chronograph → Soccer Timer)
- To Start/Stop, press A when showing Chronograph
- To Reset: Press A to stop, then B to reset
- Lap/Split: Reset to 0, then press C to switch between Lap/Split
- Pressing B while the Chronograph is running will record Laps/Splits
- Pressing C before resetting, will show the records successively:  
(Fast → Slow → Average → From the first record, to the last)



## Soccer Timer Mode

### Timer Display:

- Timer comes factory set for 45 minutes
- Press D to cycle between the 4 display modes:  
(Time → Alarm → Chronograph → Soccer Timer)
- Press B when showing Timer to Start/Stop the countdown
  - Press B and hold for 2 seconds to reset to 45'
  - When the countdown reaches 00, it will start counting up
  - 30 seconds before the time on the Stoppage timer is reached, It will give 3 short beeps continually until it matches the Stoppage Timer
  - When the Stoppage Time is reached, it will give 3 long beeps continually for 10 seconds to indicate that the playing time is over.
- Press A to Start/Stop Stoppage Time
  - Press and hold for 2 seconds to reset to 00
  - (Counting up to 59'59" will reach the limit of the Stoppage Timer It will return to 00 and continue counting)
- B) Soccer Timer Setting:
  - Timer can be adjusted from 1 to 99 minutes
- Press D to cycle between the 4 display modes:  
(Time → Alarm → Chronograph → Soccer Timer)
- When the Soccer Timers displays, press and hold C for 2 seconds
- Press A to set the desired time (in minutes)
- When the desired time has been set, press C to return to the Soccer Timer display mode.

